

INSTALLATION

Insert smaller dia. end (inside telescope) spring loaded roller from dispenser inside screw cap. Screw cap onto threaded body to contain larger (outside telescope) dia. end until R-009 length is 1/16" (1.6mm) less than spacing between dispenser posts (supplied separately). Load R-009 with toilet paper and insert into dispenser posts.

OPERATION

Paper core must be ripped off to remove R-009 after roll is exhausted. Grasp inside roller through opposing windows and retract pivot end from holder socket.

Accessory Specialties

AMERICAN DISPENSER

Desert Ray Products

THIS MANUFACTURER RESERVES THE RIGHT TO MAKE CHANGES IN DESIGN OR DIMENSIONS WITHOUT FORMAL NOTICE