

CODE NUMBER

3370068

DESCRIPTION

1.0 gpf, Rough Brass Finish, Single Flush, Solar, Less Wall Box, SOLIS® Concealed Sensor Urinal Flushometer.

DETAILS

Flush Volume: 1.0 gpf (3.8 Lpf)
Finish: Rough Brass (RB)
Power Type: Solar
Battery Life: 6 years

Valve: Diaphragm

• Valve Body Material: Semi-red Brass

• Fixture Type: Urinal

Fixture Connection: Rear spud
Rough-In Dimension: 13 ½" (343mm)

Spud Coupling: ¾" (19mm)
Supply Pipe: ¾" (19mm)
Wall Box: Less (L/BOX)

FEATURES

- "Low Battery" Flashing LED
- Four (4) Size AA Battery Back-up Power Source
- Wall Plate with Stainless Steel Access Panel and Vandal Resistant Screws
- ADA Compliant SOLIS® Solar-Powered Infrared Sensor for automatic "No Hands" operation
- Infrared Sensor with Multiple-focused, Lobular Sensing Fields for high and low target detection
- High Back Pressure Vacuum Breaker Flush Connection with One piece Bottom Hex Coupling Nut
- Fixed Metering Bypass and No External Volume Adjustment to Ensure Water Conservation
- Solar Powered. The sensor assembly is powered by a solar cell that will harvest power from the artificial indoor light (incandescent, fluorescent or LED), and use it as the energy source. The solar cell can provide approximately 100% power with 650 illuminance (lux).
- User friendly (1-2) second Auto Flush Delay
- 3/4" I.P.S. Wheel Handle Bak-Chek® Angle Stop
- Spud Coupling and Flange for 3/4" concealed Rear Spud
- Courtesy FlushTM Non-Hold-Open True Mechanical Override
- Diaphragm, Stop Seat and Vacuum Breaker to be molded from PERMEX® rubber compound for Chloramine resistance



COMPLIANCES & CERTIFICATIONS









(UL Certified, ADA Compliant, cUPC Certified, BAA Compliant)

RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

ELECTRICAL SPECIFICATIONS

• Battery Life: 6 years

VALVE OPERATING PRESSURE (FLOWING)

15–80 PSI (103–552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

DOWNLOADS

- Solis 8100 Series Installation Instructions
- Solis 8100 Series (Spanish) Installation Instructions
- Solis 8152/8195 SWB Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Concealed Solis Repair and Maintenance Guide
- Additional Downloads

NOTES

All information contained within this document subject to change without notice.

Looking for other variations of the SOLIS 8195 product? View the general spec sheet with all options.

Find a compatible urinal for this flushometer.
Find a compatible water closet for this flushometer.



ROUGH-IN

