

### AER-DEC® 81000/82000/83000/84000 INTEGRATED SINK SYSTEM




AD-81000 Deck Sink Lavatory System

#### **1 Station Components**




Description	Item Number	Quantity
•		1
AER-DEC <sup>®</sup> , One Station, Integrated Deck		
Angled Enclosure with Hold Open Door	2a	1
Vertical Enclosure with Hold Open Door	2b	1
EFX Series Faucet	3	1
Basys Style ESD 500 Soap Dispenser	4	1
Basys Style Hand Dryer	5	1
Hand Dryer Bracket	6	1
Note: Hand Dryer Motor must be rotated 90° for installation into	a standard vertical enclosure.	

## AER-DEC® 81000/82000/83000/84000 INTEGRATED SINK SYSTEM






#### **2 Station Components**




Description	ltem Number	Quantity
AER-DEC®, Two Station, Integrated Deck	1	1
Angled Enclosure with Hold Open Door	2a	1
Vertical Enclosure with Hold Open Door	2b	1
EFX Series Faucet	3	2
Basys Style ESD 500 Soap Dispenser	4	2
Basys Style Hand Dryer	5	2
Hand Dryer Bracket	6	2
Note: Hand Dryer Motor must be rotated 90° for installation into a standard vert	ical enclosure.	

# AER-DEC<sup>®</sup> 81000/82000/83000/84000 INTEGRATED SINK SYSTEM




#### **3 Station Components**



AER-DEC <sup>®</sup> Two Station Component List		
Description	Item Number	Quantity
AER-DEC <sup>®</sup> , Two Station, Integrated Deck	1	1
Angled Enclosure with Hold Open Door	2a	1
Vertical Enclosure with Hold Open Door	2b	1
EFX Series Faucet	3	2
Basys Style ESD 500 Soap Dispenser	4	2
Basys Style Hand Dryer	5	2
Hand Dryer Bracket	6	2
Note: Hand Dryer Motor must be rotated 90° for installation into a standard	d vertical enclosure.	

The information contained in this document is subject to change without notice.


# AER-DEC® 81000/82000/83000/84000 INTEGRATED SINK SYSTEM



### SLOAN.


Repair Parts and Maintenance Guide

### AER-DEC® 81000/82000/83000/84000 INTEGRATED SINK SYSTEM



#### CLEANING AND MAINTENANCE

#### **REGULAR CLEANING OF DRAIN BOX REQUIRED (if app.)**



- **3.** Lift and separate from frame.
- **4.** Clean the box and the grid strainer with a rag and disinfectant containing bleach and dispose of properly.
- 5. Close access panel.

The information contained in this document is subject to change without notice.